



GARMIN APPROACH G6, G7 or G8 Instructions

Included in your Quick Clip package are three (two spares) belt clip hook/3M adhesive disk assembly, alcohol pads for cleaning the oils, dirt, dust from the back of your G6 (this is very important as it will assure optimal adhesion), two spare 3M adhesive disks and the simple instructions. It's very important that you clean the back of your Garmin (please don't use soap and water!) with the alcohol pad. Allow it to air dry. Peel the paper backing off of the back of the belt clip hook/3M adhesive disk assembly. Very carefully place the belt clip hook on the back of your Garmin in the spot of the white square as shown in the above picture. Be careful -- once the 3M adhesive touches your Garmin, it wants to stick like crazy. Once it's in place, put pressure on it for several seconds then allow it to "cure" for 48-72 hours before using your Garmin on the Quick Clip. **VERY IMPORTANT: If you follow the directions "to the letter", the belt clip tab/3M adhesive disk assembly will stick instantly and you won't be able to remove it using your fingers/hands (you may draw blood). It certainly cannot come off during your everyday use on the golf cart.** If you ever want to take it off, simply warm the belt clip hook/3M adhesive disk with a hair dryer for several seconds. It still won't be easy to pull off but with some effort, it will peel off and usually without any residue. Don't re-use that 3M adhesive disk as it loses some of its adhesive properties when it's been removed. The belt clip hook can be re-used but be sure to clean it with alcohol before placing a new (included) 3M adhesive disk on it.

See the attached picture of the back of your Garmin G6, G7 or G8. I've added a white square on the exact position where you should place the belt clip hook/3M adhesive disk assembly for the best center of gravity. However, it's important for you to know that once the belt clip tab is on your Garmin, you won't be able to use the spring belt clip that came with your Garmin as it will not fit. If you ever do want to use the spring belt clip that comes with your Garmin, you would need to remove the belt clip tab as explained above. If you need more of the belt clip hooks, alcohol pads or 3M adhesive disks, send us an e-mail with your full name and address and we'll send them to you at no charge.

Please don't hesitate to call us at 643-333-7453 if you have any additional questions or concerns.

Mike Owens
GPS Quick Clip Inc.
mike@gpsquickclip.com