

## **BUSHNELL TOUR V 4 INSTRUCTIONS**

We've placed one of our "modified" rectangular *Quick Clip belt clip tab/3M adhesive assemblies* (see picture below) on the laser lens end of the V4 for the optimal center of gravity (see 2<sup>nd</sup> picture below). This is the precise location where you need to carefully place the belt clip tab/3M adhesive disk assembly. With your Quick Clip, we include 3 (two spares) of these belt clip tab/3M adhesive assemblies, alcohol cleaning wipes and extra 3M adhesive disks.

Using one of the included alcohol cleaning wipes, clean that spot on your V4 and allow to air dry. This removes any oils, sweat, grease and other yucky stuff so the adhesion is optimized. Peel the paper backing off of one of the belt clip tab/3M adhesive assemblies. Very carefully place the belt clip tab on the spot as shown in the V4 picture.

**CAUTION:** The belt clip tab/3M adhesive will want to stick immediately to whatever it touches so use care when placing it on the spot and try not to touch the adhesive with your fingers. Apply some pressure on the belt clip tab for about 30 seconds.

Allow it to "set and cure" for a minimum of 48 hours (72 hours if possible is even better) before using your V4 in the Quick Clip keyhole slot. That will enhance the adhesive properties of the 3M adhesive disk. The 3M adhesive is a viscoelastic polymer that is extremely strong and durable. By allowing 48 to 72 hours "curing time", the viscoelastic adhesive molds itself over time into the microscopic imperfections of the two joining surfaces. Here is a link to a 3M document that includes the full details as well as videos of the 3M VHB adhesive.

To open this link, right-click directly on the link below, then from the list of optional actions then click on "Open Hyperlink".

[https://www.3m.com/3M/en\\_US/company-us/all-3m-products/~/3M-VHB-Tape-4991?N=5002385+3293223574&rt=rud](https://www.3m.com/3M/en_US/company-us/all-3m-products/~/3M-VHB-Tape-4991?N=5002385+3293223574&rt=rud)

**VERY IMPORTANT:** If you follow the directions "to the letter", the belt clip tab/3M adhesive disk assembly will stick instantly and you won't be able to remove it using your fingers/hands (you may draw blood). It certainly cannot come off during your everyday use on the golf cart. If you ever need to remove the belt clip tab, simply warm the adhesive with a hair dryer. The adhesive will soften and you can peel off the belt clip tab, though it still won't be easy. Don't try to re-use that 3M adhesive that you peeled off as it loses some of its adhesive properties. Remove it and use a fresh 3M adhesive disk. You can re-use the black rectangular belt clip tab. Remove any remaining adhesive and clean it thoroughly with an alcohol wipe or a clean cloth with a dab of isopropyl (rubbing) alcohol. Carefully (see **CAUTION** above) place the fresh 3M adhesive disk on the belt clip tab then trim any excess 3M VHB adhesive using a razor knife.

If you need more belt clip tabs or 3M VHB adhesive, call us at 843-333-7453 or e-mail [sales@gpsquickclip.com](mailto:sales@gpsquickclip.com).

Thanks for buying our Quick Clip everyone! Please don't hesitate to contact us if you have questions or concerns.

Michael D Owens  
159 Goodson Loop  
Pawleys Island, SC 29585

Phone: 843-333-7453  
Fax: 843-235-8405

Email: [mike@gpsquickclip.com](mailto:mike@gpsquickclip.com)  
Web: [www.gpsquickclip.com](http://www.gpsquickclip.com)

(See the two pictures on the next page)

