

Laser Link Quick Shot 2.0 and Laser Link RH 2 Instructions

These two Laser Link Rangefinders (pictured below) were introduced in approximately 2014-2015 as replacements for the original Quick Shot and the Red Hot. They are identical except for the software and color so these instructions apply to both the Laser Link Quick Shot 2.0 as well as the Laser Link RH 2. Unfortunately, Laser Link wrapped the pistol grips of each with silicone rubber. To make matters even worse, our belt clip tab/3M adhesive disk assemblies do not stick adequately to silicone. But we have found a foolproof alternative of attaching the belt clip tab/3M adhesive disk assembly to each of these Laser Link Rangefinders.

See the picture below of our Laser Link RH 2 with the red pistol grip. We have placed one of our belt clip tab/3M VHB adhesive disk assemblies (see picture of them below) on one side using the instructions described below. Follow the instructions below for each method "to the letter". If you do, you'll be amazed how well it adheres. You will not be able to remove it using your fingers and it certainly cannot come off of your Laser Link during normal play of your round. But if you ever want to remove it, warm the 3M VHB adhesive with a hair dryer for a minute or so. You can then peel off the belt clip tab (though it still will not be easy).

This method requires that you cut a hole in the silicone which is very easy to do using a sharp razor utility knife (be careful with it!). **The operation of your Laser Link is not affected in any way.** Follow these steps:

1. Use one of the 3 belt clip tab/3M adhesive disk assemblies (two spares) that we include in your Quick Clip package as a template (don't actually stick it on your laser Link yet).
2. Place and hold the belt clip tab/3M adhesive disk assembly on your Quick Shot 2.0 (or RH 2) as closely as possible in the position as shown on the picture.
3. Then, using a black pen or fine point magic marker, trace a circle around the belt clip tab on the silicone (NOTE: for better visibility, you may want to use a white pen or magic marker to trace the circle on the black silicone cover on the Quick Shot 2.0). Then use your razor utility knife and very carefully cut out the traced circle and completely remove the silicone circle. That will expose the solid rigid plastic handle base of your Quick Shot 2.0 (or RH 2) pistol grip.
Important: The belt clip tab/3M adhesive disk assembly should fit completely inside the circle for optimal adhesion.
4. Be sure there is no loose or uneven silicone remaining in the space where you removed the silicone circle. Using one of the included alcohol prep pads, clean the circle and allow it to completely air dry.
5. Using one of the included belt clip tab/3M VHB adhesive disk assemblies (again see picture below), peel the paper covering the while being careful to avoid touching the adhesive. Then carefully place the belt clip tab within the circle and apply pressure for about 30 seconds. It will look like the RH 2 pictured below and if you are preparing your Quick Shot 2.0, it will look the same with the exception of the black silicone pistol group.
6. Because the 3M VHB adhesive increases its exceptional adhesive properties as it "cures", allow it to cure for **no less than 48 hours** before using. Over this time, the 3M adhesive fills the microscopic "nooks and crannies" of the rangefinder plastic. If you had followed these directions "to the letter" you will not be able to remove the belt clip tab/3M VHB adhesive disk assembly with your fingers (you may draw blood). It certainly cannot come loose when used in a normal round of golf. But if you ever want to remove it, simply warm the adhesive with a hair dryer. You can peel it off, but it will still not be easy.
7. After allowing the 48 hours to cure the adhesive, you are now ready to use your Laser Link Quick Shot 2.0 or RH 2. Due to the design of Laser Link Rangefinders and for the optimum center of gravity, all Laser Link Rangefinders are best hung on your Quick Clip with the handle up (see picture below). To attach your Laser Link to the Quick Clip, turn it with the handle right or left and place the belt clip tab in the keyhole slot of the Quick Clip. Allow the working end (top) of your Laser Link to hang straight down. To remove, reverse the process.
8. **If you have any doubts about the awesome strength of the 3M VHB adhesive**, here is a link to a 3M document that includes the full details as well as videos of the 3M VHB adhesive. To open this document, simply click on the link below:

https://www.3m.com/3M/en_US/company-us/all-3m-products/~/3M-VHB-Tape-4991/?N=5002385+3293223574&rt=rud

(scroll to page 2 pictures)



Laser Link RH 2



Laser Link Quick Shot 2.0



Belt Clip Tab/3M Adhesive Disk Assembly

