

SIMMONS LRF600 (Also called the 801600) LASER RANGEFINDER

Attached is a picture of the Simmons LRF600 showing the optimum placement (**nearer to the laser lens end**) of the belt clip hook/3M VHB adhesive disk.

As you know your LRF600 does not have a tripod. The Quick Clip package for your LRF600 will include two alcohol wipes for cleaning the surface of your LRF600 of any dirt oils, etc. (**it's very important to use the cleaning wipes as this enhances the adhesive properties**), three (two spares) belt clip tab/3M adhesive disk assemblies (see picture below) and extra 3M adhesive disks.

Using the included alcohol cleaning pad, clean the spot on your LRF600 as shown in the picture and allow to completely air dry. This removes any oils, sweat, grease and other yucky stuff so the adhesion is optimized. Peel the paper backing off of one of the belt clip tab/3M adhesive disk assemblies. Carefully place the belt clip tab on the same spot shown in the picture. **CAUTION:** The belt clip tab/3M adhesive disk assembly will want to stick immediately to whatever it touches so use care when placing it on the spot and try not to touch the adhesive with your fingers. **IMPORTANT NOTE: If you have followed these instructions "to the letter", it is very near to impossible to remove with your hands (you may draw blood) and it certainly cannot loosen up when in routine everyday use on the golf cart with the Quick Clip.** Apply some pressure on the belt clip hook for about 30 seconds.

Allow it to "set" for 48 to 72 before using your LRF600 on the Quick Clip. That will also enhance the adhesive properties of the 3M adhesive disk. If you ever need to remove the belt clip tab, simply warm the adhesive with a hair dryer. The adhesive will soften and you can peel off the belt clip tab, though it still won't be easy. Don't try to re-use that 3M adhesive that you peeled off as it loses some of its adhesiveness. Remove it and use a fresh adhesive disk. You can re-use the belt clip tab. Remove any remaining adhesive and clean it with an alcohol pad or a clean cloth with a dab of isopropyl alcohol. Carefully (see **CAUTION** above) place the fresh 3M adhesive disk on the belt clip tab.

If you need more belt clip tabs or 3M adhesive disks, call us at 843-333-7453 or e-mail mike@gpsquickclip.com. Thanks you for considering our Quick Clip.

Please don't hesitate to call us if you have any questions or concerns

Michael D Owens
159 Goodson Loop
Pawleys Island, SC 29585

Phone: 843-333-7453
Fax: 843-235-8405

Email: mike@gpsquickclip.com
Web: www.gpsquickclip.com

