

GARMIN APPROACH G3 & G5 INSTRUCTIONS

See the picture below. Both of these original version (Introduced November, 2009) Garmin Approach models came with a belt clip tab that attaches to the back of the device. Please see below the included page from the Garmin G3 and G5 user manual. So this is a “no brainer” to attach to the Quick Clip.

With the belt clip “spine attachment” attached to the back of your G3/G5, simply place the belt clip tab into the keyhole slot of the Quick Clip and slid it down to the bottom of the keyhole slot.



1GARMIN APPROACH G3 AND G5

Using the Clip

You can use the clip to mount the Approach on your belt, your pocket, or your bag.

To attach the clip:



1. Position the spine attachment in the slots on the mounting spine of the Approach.
2. Slide the spine attachment up until it locks in place.
3. Position the clip in the slot on the spine attachment.
4. Slide the clip up until it locks in place.

To remove the clip and spine attachment:

1. Press the release key on the top of the clip, and slide the clip off.
2. Lift the bottom of the spine attachment, and slide the spine off.



Course Updates

This product may be eligible for free course map updates. To update your Approach, go to www.garmin.com/CourseView.